

ASUS System Control Interface V3
A3402WBA
A5401WRP
B1400CEAES
B1400CEAEY
B1400CEAEZ
B1400CEPE
B1400CEPES
B1400CEPEY
B1400CEPEZ
B1500CBA
B1500CEAE
B1500CEAES
B1500CEAEY
B1500CEAEZ
B1500CEPE
B1500CEPES
B1500CEPEY
B1500CEPEZ
B1502CBA
B1502CGA
B1502CVA
B2402CBA
B2402FVA
B2502CBA
B2502CVA
B2502FBA
B2502FVA
B3302CEA
B5302FBA
B5402FEA
B5402FVA
B5602CBN
B5602CVN
B5602FBA
B5602FBN
B5602FVA

B9400CEAS
BR1100CKAF
BR1100FKA
BR1102FGA
BR1402FGA
D300TA
D500MD
D500ME
D500SA
D500TC
D500TD
D500TE
D700SA
D700SC
D700TC
D700TCS
D900MDR
E1404GAB
E1504FA
E1504GA
E1504GAB
E5402WHA
FA506IC
FA506ICB
FA506IE
FA506IEB
FA506IH
FA506IHR
FA506IHRB
FA506II
FA506IR
FA506IU
FA506QC
FA506QE
FA506QR
FA507NI
FA507NJ

FA507NV
FA507RC
FA507RE
FA507RM
FA507RR
FA507XI
FA507XJ
FA507XQ
FA507XV
FA607RC
FA607RE
FA607RH
FA607RM
FA607RR
FA607RW
FA617NS
FA617XS
FA706IC
FA706ICB
FA706IE
FA706IEB
FA706IH
FA706IHR
FA706IHRB
FA706II
FA706IM
FA706IR
FA706IU
FA706QC
FA706QE
FA706QM
FA706QR
FA707NI
FA707NJ
FA707NU
FA707NV
FA707RC

FA707RE
FA707RF
FA707RH
FA707RM
FA707RR
FA707RW
FA707XI
FA707XIN
FA707XJ
FA707XQ
FA707XU
FA707XV
FX506HC
FX506HCB
FX506HE
FX506HEB
FX506HH
FX506HMB
FX506LH
FX506LHB
FX506LU
FX507VI
FX507VI4
FX507VJ
FX507VJ4
FX507VU4
FX507VV
FX507VV4
FX507ZC
FX507ZE
FX507ZE4
FX507ZH
FX507ZI4
FX507ZJ4
FX507ZM
FX507ZR
FX507ZV4

FX516PC
FX516PE
FX516PEB
FX516PR
FX517ZC
FX517ZE
FX517ZH
FX517ZM
FX517ZR
FX607VI
FX607VJ
FX607VU
FX607VV
FX607ZC
FX607ZE
FX607ZH
FX607ZM
FX607ZR
FX607ZW
FX617ZC
FX617ZE
FX617ZH
FX617ZM
FX617ZR
FX617ZW
FX706HC
FX706HCB
FX706HE
FX706HEB
FX706HF
FX706HH
FX706HM
FX706HMB
FX706LH
FX706LI
FX707VI
FX707VI4

FX707VIN
FX707VJ
FX707VJ4
FX707VJN
FX707VU
FX707VU4
FX707VUN
FX707VV
FX707VV4
FX707VVN
FX707ZC
FX707ZC4
FX707ZE
FX707ZE4
FX707ZH
FX707ZI4
FX707ZIN
FX707ZJ4
FX707ZJN
FX707ZM
FX707ZR
FX707ZU4
FX707ZUN
FX707ZV4
FX707ZVN
FX707ZW
G10CES
G10DK
G10DK-C
G513IC
G513IE
G513IH
G513IR
G513QC
G513QE
G513QH
G513QR

G513RC
G513RE
G513RH
G513RM
G513RR
G513RS
G513RX
G533QM
G533QR
G533QS
G533ZC
G533ZE
G533ZM
G533ZS
G533ZX
G614JJ
G614JU
G614JV
G614JZ
G634JY
G634JZ
G713IC
G713IE
G713IH
G713IM
G713IR
G713PU
G713PV
G713PVN
G713QC
G713QE
G713QH
G713QM
G713QR
G713QY
G713RC
G713RE

G713RH
G713RM
G713RR
G713RS
G713RW
G713RX
G733CM
G733CX
G733PY
G733PYV
G733PZ
G733QM
G733QR
G733QS
G733QSA
G733ZC
G733ZE
G733ZM
G733ZS
G733ZW
G733ZX
G814JI
G814JU
G814JV
G814JZ
G834JY
G834JZ
GA401IC
GA401IHR
GA401QC
GA401QE
GA401QH
GA402NI
GA402NJ
GA402NV
GA402RI
GA402RJ

GA402RU
GA402RW
GA402XU
GA402XV
GA402XY
GA402XZ
GA503IC
GA503IE
GA503IH
GA503QC
GA503QE
GA503QH
GA503QM
GA503QR
GA503RJ
GA503RM
GA503RS
GA503RX
GU603HE
GU603HM
GU603VI
GU603VV
GU603ZEB
GU603ZI
GU603ZM
GU603ZV
GU603ZX
GU604VY
GU604VZ
GV301QCZ
GV301QE
GV301QEZ
GV301QH
GV301QHZ
GV301RA
GV301RE
GV302NA

GV302NF
GV302NI
GV302NU
GV302XA
GV302XF
GV302XI
GV302XJ
GV302XU
GV601RE
GV601RM
GV601RW
GV601VI
GV601VJ
GV601VU
GX551QM
GX551QN
GX551QR
GX650PI
GX650PU
GX650PV
GX650PZ
GX650PZV
GX650RM
GX650RS
GX650RW
GX650RX
GZ301VF
GZ301VIC
GZ301VJC
GZ301VQC
GZ301VU
GZ301VUC
GZ301ZA
GZ301ZC
GZ301ZE
H5600QR
H7600ZM

H7600ZW
H7604JV
K3405VC
K3405VF
K3405ZA
K3502ZA
K3605VA
K3605VJ
K3605VU
K3605ZA
K3605ZC
K3605ZU
K5504VN
K6500ZC
K6502HE
K6502VJ
K6502VJQ
K6502VV
K6502ZE
K6602HC
K6602HE
K6602VU
K6602VV
K6602ZC
K6602ZE
K6604JV
L1400CDAP
L1400CDAY
L1500CDA
L1500CDAP
L1500CDAY
L2402CYA
L2502CYA
L2502FYA
M1502IA
M1502YA
M1503IA

M1503QA
M1505YA
M1603IA
M1603QA
M1605YA
M1702QA
M1703QA
M3400WUA
M3400WYA
M3401QA
M3500QC
M3502QA
M3502RA
M3604YA
M3700WUA
M3700WYA
M3702WFA
M3704YA
M5602QA
M5602RA
M6400QH
M6500QE
M6500QH
M6500RC
M6500RE
M6500XV
M6501RR
M7400QE
M7400QEB
M7600QA
M7600QC
M7600QCB
M7600QE
M7601RM
N7601ZW

P1512CEA
P2451FB
RC71L
RC71X
S501MD
S501ME
S502ME
S5602ZA
T3304GAB
TP1401KA
UM5401QAB
UM6702RC
UN5401QA
UN5401QAB
UN5401RA
UP6502ZD
UX325UA
UX3404VC
UX425EA
UX435EGL
UX482EG
UX482EGR
UX535LI
UX535QE
UX5400EG
UX5400ZB
UX5401ZAS
UX582HM
UX6404VV
UX8402VU
UX8402ZE
V222FB
V241EP

W5600Q2A
W7600H5A
W7604J3D
X1403ZA
X1504VA
X1504ZA
X3400PH
X3400PHB
X409FB
X409FJ
X409FL
X415DAP
X415EP
X415EPN
X415JF
X415JP
X421EPYB
X421EQYB
X421UAY
X509FAC
X513EPN
X513EQN
X515DA
X515DAP
X515EA
X515EAN
X515EP
X515EPN
X515JA
X515JAB
X515JF
X515JP
X515KA
X515MA
X515UA
X571GD
X712EQ

X7400PCB
A3202WBA
A5200WFA
A5200WFP
A5200WGA
A5200WIA
A5200WRA
A5200WRP
A5202WVA
A5400WFA
A5400WFP
A5400WGA
A5400WIA
A5400WRA
A5400WRP
A5401WRA
A5402WVA
A5702WVA
B1100CKA
B1100FKA
B1400CBA
B1400CEA
B1400CEAE
B1400CEP
B1402CBA
B1402CGA
B1402CVA
B1500CEA
B1500CEP
B2402CVA
B2402FBA
B3302FEA
B3400CEA
B3400CEG
B3402FBA
B3402FEA
B3500CEA

B3500CEG
B5302CBA
B5402CBA
B5402CBAW
B5402CEA
B5402CEAW
B5402CVA
B5402FBA
B5602CBA
B5602CVA
B6602FC2
B7402FBA
B7402FEA
B7402FVA
B9400CBA
B9400CBAV
B9400CEA
B9400CEAV
B9403CVA
B9440FA
B9440FAV
B9450FA
B9450FAV
BR1100CKA
BR1102CGA
BR1402CGA
D425MC
D500SC
D640MB-R
D641MD
D641SC
D642MF
D700MD
D700ME
D700TA
D700TD
D700TE

D800MDR
D900MC
D900MD
D900TA
D940MX
E1404FA
E1404GA
E1600WKA
E203MAR
E203MAS
E210KA
E210MA
E210MAB
E402YA
E406MAS
E406NA
E407MA
E410KA
E410MA
E410MAB
E510KA
E510MA
E510MAB
E5202WHA
FA506IM
FA506IV
FA506QM
FA507NU
FA507RF
FA507RW
FA507XU
FA617NT
FA617RS
FA617XT
FX505DD
FX505DT
FX505DU

FX505DV
FX505DY
FX505GD
FX505GE
FX505GM
FX505GT
FX505GU
FX506HF
FX506HHR
FX506HM
FX506LI
FX507VU
FX507ZC4
FX507ZU4
FX507ZW
FX516PH
FX516PM
FX517ZW
FX605DV
FX705DD
FX705DT
FX705DU
FX705DV
FX705DY
FX705GD
FX705GE
FX705GM
FX706HHR
G10CE
G13CH
G13DS
G15CE
G15CF
G15CK
G15CS
G15CX
G15DK

G15DK-C
G15DS
G16CH
G21CN-D
G21CX
G22CH
G35CA
G35CG
G35CZ
G512LH
G512LI
G512LU
G512LV
G512LW
G512LWS
G513IM
G513QM
G513QY
G513RW
G531GD
G531GT
G531GU
G531GV
G531GW
G532LU
G532LV
G532LW
G532LWS
G533ZW
G614JI
G703GX
G703GXR
G712LI
G712LU
G712LV
G712LW
G712LWS

G713PI
G731GD
G731GT
G731GU
G731GV
G731GW
G732LU
G732LV
G732LW
G732LWS
G732LXS
G733CW
G733PZV
GA15DH
GA15DH-S
GA35DX
GA401IE
GA401IH
GA401II
GA401IU
GA401IV
GA401IVC
GA401QEC
GA401QM
GA401QMC
GA402NU
GA402RK
GA402RX
GA402XI
GA502II
GA502IU
GA502IV
GA503IM
GA503QN
GA503QS
GA503RK
GA503RW

GL10CS
GL10DH
GL12CS
GL12CX
GL12CX-C
GL504GV
GL504GW
GL703GM
GL704GM
GL704GMC
GL704GS
GL704GSC
GL704GV
GL704GW
GU502DU
GU502GU
GU502GV
GU502GW
GU502LI
GU502LU
GU502LV
GU502LW
GU502LWS
GU603HR
GU603VU
GU603ZU
GU603ZW
GU604VI
GV301QA
GV301QC
GV301RC
GV302NJ
GV302NV
GV302XV
GV601VV
GX502GV
GX502GW

GX502GWH
GX502LWS
GX502LXS
GX531GM
GX531GS
GX531GV
GX531GVH
GX531GVR
GX531GW
GX531GWH
GX531GWR
GX531GX
GX531GXH
GX531GXR
GX550LWS
GX550LXS
GX551QS
GX650PY
GX650PYV
GX701GV
GX701GVR
GX701GW
GX701GWR
GX701GX
GX701GXH
GX701GXR
GX701LV
GX701LW
GX701LWS
GX701LXS
GX703HM
GX703HMD
GX703HR
GX703HRD
GX703HS
GX703HSD
GZ301VV

GZ301VVC
GZ700GX
GZ700GXH
H5600QE
H5600QM
H7600HM
H7600ZX
H7604JI
I1403QA
I1403VA
I1403ZA
I1405VA
I1405YA
I321EA
I321JA
I321JP
I321JQ
I330FA
I330FAC
I330FL
I330FLC
I330FN
I330UA
I330UN
I403FA
I403FAC
I403JA
I421EA
I421EAY
I421EQ
I421EQY
I421FA
I421FAY
I421FL
I421FPY
I421FQY
I421UAY

K3402ZA
K3405VA
K3405ZF
K3504VA
K3504ZA
K3604VA
K3604ZA
K3605VC
K3605VV
K3605ZF
K3605ZV
K3704VA
K5504VA
K6400ZC
K6500ZE
K6500ZH
K6501ZM
K6501ZMB
K6502HC
K6502VU
K6502ZC
K6604JI
L1400CDA
L2402FYA
L424FA
L424FB
L524FA
L524FB
M1402IA
M1403QA
M1405YA
M1502QA
M1605XA
M3200WUA
M3200WYA
M3400QA
M3401QC

M3402QA
M3402RA
M3402WFA
M3500QA
M3504YA
M5401WUA
M5401WYA
M5402QA
M5402RA
M6400QB
M6400QC
M6400RC
M6500IH
M6500QB
M6500QC
M6500QF
M6500XU
M6501RM
M7400QC
M7600RE
MJ201MA
MJ401TA
N7401ZE
N7600ZE
N7601ZM
P1412CEA
P1440FA
P1440FAC
P1440FAI
P1440FB
P1440FBI
P2451FA
P2451FAV
P2451FAW

P2540FAC
P2540FB
P2540MB
P2540UBP
P3540FA
P3540FB
P5240FA
P5240FF
P5340FA
P5340FF
P5440FA
P5440FAI
P5440FF
P5440FFI
P700TA
PD500TC
PD500TE
Q326FA
Q406DA
Q406FA
Q506FA
Q526FA
Q536FD
Q536FDX
Q537FD
R415JP
R415UA
R421EAY
R421EPY
R421FAY
R421FFY
R421FPY
R421IAY
R515JP
R515UA
S300MC
S340MF

S512DA
S5402ZA
T3300KA
T3304GA
TN3402QA
TN3402YA
TN3604YA
TP1400KA
TP203MA
TP203MAH
TP203MAS
TP3402VA
TP3402ZA
TP3604VA
TP401CAS
TP401MA
TP401MAR
TP401MARB
TP401MAS
TP412FA
TP412FAC
TP420IA
TP420UA
TP470EA
TP470EZ
UM3402YA
UM3402YAR
UM3504DA
UM5302LA
UM5302TA
UM5401QA
UM5401RA
UM5401UA
UM6702RA
UN5401UA
UP3404VA
UP5302ZA

UP5401EA
UP5401ZA
UP6502ZA
UX325EA
UX325JA
UX325SA
UX325UAZ
UX331FA
UX331FAL
UX331FN
UX333FA
UX333FN
UX334FA
UX334FAC
UX334FL
UX334FLC
UX3402VA
UX3402ZA
UX3404VA
UX362FA
UX363EA
UX363JA
UX391FA
UX392FA
UX392FN
UX393EA
UX393JA
UX425IA
UX425JA
UX425QA
UX425UA
UX425UAZ
UX425UG
UX431DA
UX431DL
UX431FA
UX431FAC

UX431FL
UX431FLC
UX431FN
UX433FA
UX433FN
UX434DA
UX434FA
UX434FAC
UX434FAW
UX434FL
UX434FLC
UX434FQ
UX434FQV
UX434IQ
UX435EA
UX435EAL
UX435EG
UX450FD
UX450FDA
UX450FDX
UX461FA
UX461FN
UX462DA
UX462FA
UX463FA
UX463FL
UX481FA
UX481FAY
UX481FL
UX481FLY
UX481FZ
UX482EA
UX482EAR
UX5304VA
UX533FD
UX533FN
UX534FA

UX534FAC
UX534FT
UX534FTC
UX535LH
UX535QA
UX535QH
UX5400EA
UX5400ZA
UX5400ZF
UX5401EA
UX5401EAJ
UX5401ZA
UX5401ZAJ
UX562FA
UX562FAC
UX562FD
UX562FDX
UX562IA
UX562IQ
UX562UG
UX563FD
UX564EH
UX564EI
UX564PH
UX581GV
UX581LV
UX582HS
UX582LR
UX582LU
UX582LV
UX582ZM
UX582ZW
UX6404VI
UX7602BZ
UX7602VI
UX7602ZM
UX8402VV

UX8402ZA
UX9702AA
V161GAR
V222FA
V222GAR
V241DA
V241DAP
V241EA
V241FA
V241FF
W500G5T
W500GV
W500GVA
W590G6T
W700G1T
W700G2T
W700G3P
W700G3T
W700GV
W700GVA
W730G1T
W730G1TV
W730G2T
W730G2TV
W730G4T
W730G4TV
W730G5T
W730G5TV
W7600H3A
W7600Z3A
X1402ZA
X1404VA
X1404ZA
X1405VA
X1405ZA
X1502VA
X1502ZA

X1503ZA
X1505VA
X1505ZA
X1603ZA
X1605EA
X1605PA
X1605VA
X1605ZA
X1702ZA
X1703ZA
X1704VA
X1704ZA
X321EA
X321JA
X321JP
X321JQ
X330FA
X330FAC
X330FL
X330FLC
X330FN
X330UA
X330UN
X3400PA
X3400PAB
X3500PA
X3500PAB
X3500PC
X3500PCB
X3500PH
X3500PHB
X403FA
X403FAC
X403JA
X406UAS
X407UAR
X407UBR

X407UF
X409BA
X409DA
X409DAP
X409DJ
X409DL
X409FA
X409FAC
X409JA
X409JB
X409JP
X409MA
X409UA
X409UB
X409UJ
X411QA
X411QR
X411UAO
X411UAS
X411UNO
X412DA
X412DAP
X412DK
X412FA
X412FAC
X412FAG
X412FJ
X412FJC
X412FJG
X412FL
X412FLC
X412FLG
X412UA
X412UB
X412UF
X415DA
X415EA

X415EAN
X415FAC
X415JA
X415JAB
X415KA
X415MA
X415UA
X420FA
X420FAC
X420UA
X421DA
X421DAP
X421DAW
X421EA
X421EAY
X421EAYB
X421EPY
X421EQ
X421EQY
X421FA
X421FAY
X421FFY
X421FL
X421FPY
X421FQY
X421IA
X421IAY
X421JA
X421JAY
X421JFY
X421JPY
X421JQ
X421JQY
X421UA
X430FA
X430FN
X430UA

X430UF
X430UN
X431FA
X431FAC
X431FL
X431FLC
X432FA
X432FAC
X432FL
X432FLC
X435EA
X441MAR
X441UAR
X441UBR
X500MA
X509BA
X509DA
X509DAP
X509DJ
X509DL
X509FA
X509FB
X509FJ
X509FL
X509JA
X509JB
X509JP
X509MA
X509UA
X509UB
X509UJ
X510QA
X510QR
X510UAD
X510UAO
X510UFD
X510UFO

X512DA
X512DAP
X512DAPU
X512DAU
X512DK
X512FA
X512FAC
X512FAG
X512FAY
X512FB
X512FBC
X512FJ
X512FJC
X512FJG
X512FL
X512FLC
X512FLG
X512JA
X512JAU
X512JAW
X512JF
X512JP
X512JQ
X512UA
X512UB
X512UF
X513EA
X513EAN
X513EP
X513EQ
X513FA
X513FF
X513FP
X513IA
X513UA
X515EAU
X515FAC

X521EA
X521EQ
X521FA
X521FL
X521IA
X521JQ
X521UA
X530FA
X530FN
X530UAO
X530UFO
X530UNO
X531FA
X531FAC
X531FL
X531FLC
X532EQ
X532FA
X532FAC
X532FL
X532FLC
X5400EA
X5400EG
X540BA
X540BP
X540MAR
X540UB
X543UB
X545FA
X545FB
X545FJ
X5500EA
X5500EG
X555QAT
X555QGT
X570DD
X571GH

X571GI
X571GT
X571LH
X571LI
X705BA
X705FD
X705FN
X705MAR
X705QA
X705QR
X712DA
X712DAP
X712DK
X712EA
X712FA
X712FAC
X712FB
X712FBC
X712JA
X712UA
X7400PA
X7400PAB
X7400PC
X7600PC
X7600PCB
Z272SD